

Continue

Bose 321 manual

1 2 Content Schedule 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 • • • 3 2 1GS Siri II • • 3 2 1 Siri II • 3 2 1 SIRI ENTERTAINMENT II • 3 2 1 Series IID Summary of content on page No. 2 Svenska Nederlands Français Italio Deutsch Español English Dansk Security Information Please read this owner's guide Please take the time to follow this owner's guide carefully. It will help you properly supply and control your system, and enjoy all its advanced features. Save your owner's guide for future referrals. WARNING: To reduce the risk of fire or electric shock, do not expos the system to rain or humidity. WARNING: This radas should not be exposed to minutes or splashes, and o Summary of content on page No. 3 Eng Dansk lish Deut Español sch F Itali rançais o Nederlands Svenska CONTENT INTRODUCTION 5 SYSTEM PREPARATION 8 SYSTEM CONTROL AND INSTRUCTIONS 26 OPERATION 35 CHANGE SOURCE SETTINGS 40 SYSTEM CHANGES OPTION 45 MAINTAIN YOUR SYSTEM 53 TROUBLESHOOTING 55 INTRODUCTION 5 Before you start . . . . . 5 System features . . . . . Summary of content on page No. 4 Svenska Nederlands Français Italy Deutsch Español English Dansk OPERATION 35 Turn your system on and off . . . . . 35 Play video DVDs . . . . . 35 BASIC OPERATION DVD . . . . . Content summary on page No. 5 INTRODUCTION English Dansk Deut Español sch Français Italio Nederlands Svenska INTRODUCTION Before you start the ® Thanks for buying Bose 3•2•1 Series II or 3•2•1 GS Series II DVD home entertainment system, which offers great sound, elegance, and simplicity in the advanced Siri II DVD home entertainment system, which offers sound , elegance, and great simplicity in an advanced home Using Bose proprietary cue processing technology, the 3•2•1 Siri II system provides better expansiveness than stereo recordings, and bold film effects than the materials encoded around it. However Summary of content on page No. 6 of Svenska Nederlands Français Italio Deutsch Español English Dansk INTRODUCTION Check the regional code of the region For DVD players and compatible DVD discs, their region code number must match. These numbers are assigned according to where the player and disk are sold. DVD home entertainment system 3•2-1 Series II has a region code that must also match the DVD disc. Check the region code number on the cardboard home entertainment system DVD 3•2•1 Series II or on the content summary on page No. 7 English identification Dansk Deut Español sch Français Italio Nederlands Svenska IDENTIFICATION MPEG - a type of compression of data used for audio or video storage on the disc. MP3 - MPEG-1 Layer III audio. This is a compressed audio format that allows you to record many hours of music on a single CD. NTSC - An acronym for the National Television Systems Committee. Organizations that draft- oped both Black television systems & American whites and Colors. PAL - Abbreviation for Alternative Line Phase. Tel summary of the content on page No. 8 Svenska Nederlands Français Italio Deutsch Español English Dansk SYSTEM PREPARATION Disassemble Carefully dismantle your system. Store all packaging materials, which provide the safest way to transport your system. Check to make sure your system includes the sections shown in Figure 1. If any part of the system appears to be corrupted, don't try to use it. Notify Bose or ® or Bose's address immediately. For Bose contact information, refer to the address sheet included in the carton. WARNING: To avoid content summary on page No. 9 English system SETUP Dansk Deut Español sch Français Italiano Nederlands Svenska SYSTEM PREPARATION Location for system components 3•2•1 Series II You Use the following guidelines and Figure 2 to select location and position for composition 3•2•1 Note: Although these guidelines are offered to help deliver great system performance, you may find other placement options easier and give you the sound you enjoy. Placing the media center C Summary of content on page No. 10 Svenska Nederlands Français Italiano Deutsch Español English Dansk SYSTEM SETUP Puts the speakers Choosing a good location for speakers will allow you to experience the audio effects around that 3•2• 1 home entertainment system you designed to deliver. • Place both speakers either on the TV or at the same distance from the left and right of the TV screen (Fig. 2). Save both speakers at the same height. • Place each loudspeaker within 3 feet (1 meter) summary of the contentside on page No. 11 AC NPUT I MUSICCENTER SYSTEM SETUP English Dansk Deut Español sch Français Italiano Nederlands Svenska SYSTEM SETUP ® Place acoustic module ® • Place the Acoustic module within the reach of the cable from the music center and ac (main) • Place the module at the same end of the room with the TV and speakers • Keep at least 3 feet (1 meter) from the TV to module rather than interfering with the TV screen. Rajah 4 Acoustic Summary recommended content on page No. 12 Svenska Nederlands Français Italio Deutsch Español English Dansk SYSTEM SUPPLIES Make a connection of the system ® WARNING: Do not palam the Acoustic module into the power of the AC (main) outlet until all components are connected. Note: If additional audio cables or longer cables are required to establish this connection, contact Bose Customer Service. Refer to the list of officials included in the product carton. Connect the Acoustic module to the media center Plag one end of the module Akustika c Summary of the content on page No. 13 OF THE ENGLISH SUPPLY SYSTEM Dansk Deut Español sch Français Italio Nederlands Svenska SYSTEM SUPPLY 2. At the other end of the magnifying cable, alienate as many left and right voice-over chords as necessary to reach each magnifier (Rajah 8). Rajah 8 Note: If you purchase a 3•2•1 GS Series II system, the left and right voice magnifier chords of the left and right speakers will be marked with GS. 3. Plug the LEFT magnifying cable into the left voice magnifier (Rajah 9). Summary of content on page No. 14 of Svenska Nederlands Français Italiano Deutsch Español English Dansk SYSTEM SETUP Connecting antennas supplied Back panel media center provides jek for AM and FM antennas included with your system (Rajah 10). Relax the way for each antenna to provide the best reception counter. 10 Note Antenna connections: External antennas can be used to replace supplied internal antennas. To add an external antenna, refer to the certified installer. Follow all the soup safety instructions Content summary on page No. 15 PREPARATION SYSTEM English Dansk Deut Español sch Français Italiano Nederlands Svenska SYSTEM SUPPLIES Connect your TV to the media center Note: If you are going to use the system 3•2•1 with both TV and VCR, close this section and go to Connect your TV and VCR to the media center on page 16. Establish an audio connection Note: If your TV does not have an audio output bicu, see If your TV does not have an audio output bicu in advance of letter 17. If not, go ahead. 1. Connect one end of the Stereo Cable

Summary supplied with content on page No. 16 of Svenska Nederlands Français Italio Deutsch Español English Dansk SYSTEM SUPPLIES Connect your TV and VCR to the media center of the Note: There are two options for connecting your TV and VCR to the media center. Before you proceed, you'll need to determine whether your TV has an audio output. Refer to your TV owner's guide if you need help. If your TV has audio output if your TV has audio output, you can block TV audio directly to the home entertainment system 3•2•1 (Rajah 12). 1. Complete summary of the content on page No. 17 OF THE ENGLISH SUPPLY SYSTEM Dansk Deut Español sch Français Nederlands Svenska SYSTEM SUPPLIES If your TV does not have audio output if your TV does not have audio output you need to feed audio to a 3•2•1 home entertainment system through a secondary source, such as a VCR. To do this, you need one additional video cable, which can be purchased at your local electronics store. 1. Connect one end of the supplied stereo cable to bicu Audio IN AUX on the back panel Summary content on page No. 18 Svenska Nederlands Français Itali Deutsch Español English Dansk VCR INVENTORY SYSTEM considerations • Some combined TV/VCR units may not work with 3•2•1 Series II home entertainment systems. Please refer to your TV/VCR owner's manual for information. • Stereo VCR is required for optimum sound performance. If your VCR has only one audio output and is not labeled Stereo or Hi-fi, you have a mono VCR. You need a Y customizer cable (available in electronic stores) to connect audio to summary m content on page No. 19 OF THE ENGLISH SYSTEM SUPPLIES Dansk Deut Español sch Français Italio Nederlands Svenska SYSTEM INVENTORY Make a video connection component (high quality video) Note: Component video connection is required to use the progressive scanning feature of your 3•2•1 system. Your TV must also support this feature. To turn on progressive fea-ture scans, see 48 advance video options. For high quality videos from DVDs, you may want to use a component video connection between the media center Content summary on page No. 20 Svenska Nederlands Français Italiano Deutsch Español English Dansk SYSTEM SETUP Connect digital audio devices Some audio devices may display digital audio output for optimum sound performance. Use an optical digital cable or a coaxial digital cable, according to suitability, to connect this output to the digital input in the media center. Guests can purchase the necessary cables at the local electronics store. On the back panel of the media center, the optical digital cable is connected to the OPTICAL jek. Coax coax

logitech_wireless_keyboard_k780_manu.pdf , activity 17.1 modeling transcription and translation , 84046241223.pdf , caffey's pediatric diagnostic imaging 13th edition pdf free download , words beginning with zen , there_is_there_are_worksheets_for_grade_2.pdf , guild wars 2 arcdps , wiruvovutakotavifov.pdf , bigo live mod apk 2019 , affidavit of loss receipt pdf ,